

Hydro Unit Maintenance Checklist

Use the space below to confirm maintenance has been completed at recommended intervals. [Scan the QR code to the right](#) to access documents, watch videos, and order parts from Dogtopia Marketplace.



WEEKLY water flush	<ul style="list-style-type: none"> • Pull tubing out of cleaning product, remove pick-up strainer and weight to drain excess product back into the supply bucket. • Raise slack of tubing to allow gravity to empty product from tube into supply bucket. • Insert pick-up hose into bucket of clean water. • Set the selector knob at each setting and flush for one minute: <ol style="list-style-type: none"> 1. Mop Bucket › Banner and Lemon 2. Spray Bottle › Banner and Lemon 				
	WEEK 01	WEEK 02	WEEK 03	WEEK 04	WEEK 05

MONTHLY dilution test	<ul style="list-style-type: none"> • See printed instructions or scan QR code above to watch a video tutorial. • If you are having issues with your hydro unit and the dilution test yields negative results, move to the quarterly step. Inspect, clean, or replace parts. 											
	JAN	FEB	MAR	APR	MAY	JUN	JUL	AUG	SEP	OCT	NOV	DEC

QUARTERLY clean, inspect, or replace parts	<ul style="list-style-type: none"> • Pick-up strainer: Remove pick up tube from cleaning product, remove pick up strainer from end of each tube and clean with warm water. Inspect for damage such as build-up on the screen or a broken screen. Replace with a new pick-up strainer if broken. Return clean or new pick-up strainer and weight to the end of each tube. • Inlet strainer: Remove water hose from water inlet attached to the side of the Hydro unit. Remove inlet strainer washer from Hydro, inspect for debris or hard water deposits. Clean with water or a soft bush. Return inlet strainer or replace if damaged or clogged. • If your dilution test yields negative results at any time, replace the Y pick-up assemblies and tips. It is recommended to replace the full Y pick-up assembly and not the individual valves. Recommend replacing quarterly. 			
	Q1	Q2	Q3	Q4